

## CONNECTING THE MODULE

#### Prior to wiring the module to the power supply, always make sure the power supply is switched off

- 1. Connect module OMC 8111-8UNI to the main module using an included connector cable
- (female connectors are located at the top of the module housing and protected by a circular rubber plug) 2. Switch on the power supply of the whole system
- 3. Assign an address to the newly connected module (see Edit Modules setting below)
- 4. Switch off the power supply of the whole system

#### ENTERING THE MENU OF OMC 8000

Instrument's menu can be entered in two different ways:

- By pressing the OK key while the screen which lists the connected modules is displayed and hold it for the entire duration of its projection. Alternatively the OK key can be kept pressed already from the moment of Power-on.
- 2. By pressing the UP and DOWN keys simultaneously for 3 seconds (Arrow Up and Arrow Down) provided the PLC program is not running (LED RUN is not on). Only in this way the menu item Start can be accessed.

orbit	<b>OMC 8000</b> 192. 168. 1. 48
	12.04.16 14:22:45
Language Password Quick start Block debug Autorecovery RTC Display	English **** No No Yes
Edit modules	
Reread modules	
<u> Ethernet</u>	

#### EDIT MODULES SETTING

This menu item allows assigning addresses to connected modules. In case there is no module connected, the screen is empty.

Changes realized in this setting are executed immediately. Pressing the **ESC** key does notmean the setting has not been already saved.

Keys  $\mbox{UP/DOWN}$  are used to select the module which is to be assigned. LED  $\mbox{RUN}$  flashes on the momentarily selected module.

Pressing the  $\rm OK$  key activates the module to be assigned. The module's details are shown in inverse colors on the display.

UP/DOWN keys rank the module into the desired position in the list.

The OK button Unhighlights the module.

ESC key terminates the process of assigning addresses.

### **RE-READ MODULES SETTING**

Resets the table of modules and reads it again. The rest is as described above.



OMC 8000





MINI-TECHDOK - OMC 8111-8UNI - 2016 - 2v0 - ei

#### ANALOGUE INPUTS

Number	8
Туре	analogue, universal
Isoloted inputs	no
Range	060/450 mV, 02,8/10/30 V ()/420 mA 0390/3900 0 P+ 100/1 000/Ni 1 000 T/C- J/K/T/E/8/S/R/N/L PNP/NPMContact (0.5/500 kHz) IRC (500 kHz), (2x)
Resolution	12 bits
Overload capacity	10x
Cold Junction Comp.	yes
Accuracy	0,2 % of range
Rate	1 000 measurements/s
LED signalisation	VES

#### TECHNICAL SPECIFICATION

TC	50 ppm/°C
Task	1 ms
Communication	CANBUS with speed of 1 Mbit/at 40 meters
Watch-dog	reset after 500 ms
Calibration	at 25°C and 40 % r.h.
POWER SUPPLY	
Power supply	via bus
Consumption	max. 330 mA

#### MECHANICAL PROPERTIES

Material	PA 66, incombustible UL 94 V-0, blue
Dimensions	36 x 91 x 60 mm
Mechanical fixation	on DIN rail 35 mm wide

#### OPEARTING CONDITIONS

Connection	screw terminals, cross section < 2,5 mm <sup>2</sup>
Operating temperature	-20°60°C
Storage temperature	-20°85°C
IP rating	IP20
Execution	Safety class I
El. safety	EN 61010-1, A2
Dielectric strength	2,5 kVAC for 1 min. between power/bus and inputs
Isolation resistance	for pollution degree II, measuring cat III 300 V (PI), 150 (DI)
EMC	EN 61326-1 (Industrial environment)
Seismic capacity	IEC 980: 1993, art.6
N. Delesses leaderline DI. Devide leaderline	

Primary isolation, DI - Double

Power supply leads should not be in the vicinity of the low level input signal leads. Contactors, electrical motors and other power devices are

Input signal leads (measured value) should be at a safe distance from all power lines and appliances. Even though this device has been successfully tested in accordance with international standards for use in industrial areas, we still recommend to adhere to the afore mentioned simple rules.

If the manufacturer is to assume the warranty conditions provided for the device's proper functionality it is essential that the shielding of the input signal wires is connected to the metal frame of the electrical switchboard!

# **OMC 8111-8UNI** CONNECTION

#### OMC 8111-8UNI







#### ection of analogue inputs



