

Update process

- 1) Download the latest packages of firmware (Fw) and system (Sys)
- 2) Create a directory called "omr700-upgrade" in the root directory of your USB Flash.
- 3) Copy both packages into this directory
- 4) Plug the USB Flash in the device and make sure it's been recognized (in Diagnostics)
- 5) Open the "Device update" dialog in the main menu
- 6) As source choose "USB" and press "Load packages"
- 7) The fields "Firmware" and "System" should now display versions of the downloaded packages
- 8) Click on the "Update" button and wait for the process to finish.
- 9) After the process is finished (doesn't take more than 10 minutes) a popup should open asking you to restart the device. Press "Yes".
- 10) After restarting the device, open the "About" dialog and make sure the firmware and system versions are correct.