

OM 371PWR

3 3/4 DIGIT PROGRAMMABLE

AC VOLTMETER/AMMETER
NETS ANALYSER
WATTMETER



1

SAFETY INSTRUCTIONS

Please, read the enclosed safety instructions carefully and observe them!
Thse instruments should be safeguarded by isolated or common fuses (breakers)!
For safety information the EN 61 010-1 + A2 standard must be observed.
This instrument is not explosion-safe!

TECHNICAL DATA

Measuring instruments of the OM371 series conform to the European regulation 89/336/EWG and the Ordinance 168/1997 Coll.

They are up to the following European standards: EN $55\,022$, class B

EN 61000-4-2, -4, -5, -6, -8, -9, -10, -11

The instruments are applicable for unlimited use in agricultural and industrial areas.

CONNECTION

Supply of energy from the main line has to be isolated from the measuring leads.



ORBIT MERRET, spol. s r.o.

Vodnanska 675/30 198 00 Prague 9

Tel: +420 - 281 040 200 Fax: +420 - 281 040 299 e-mail: orbit@merret.cz







1. CONTENTS

	rents		••••••		
Connection					
Setti					
			8		
			ns		
4.1			he (-) sign		
	User me		num instrument setting, calibration		
+.Z	4.2.1		ue resetting		
	4.2.1		limits		
	4.2.3		data output		
	4.2.4		analog output		
2		•	ů 1		
1.3	Configu	ration menu		14	
	4.3.1		on mode - INPUT		
		4.3.1.1	Values resetting (min/max, tare)		
		4.3.1.2	Instrument configuration		
		4.3.1.3	Auxiliary inputs	1.	
	4.3.2	Configurati	on mode - CHANNELS		
		4.3.2.1	Channel "I"		
			4.3.2.1.1 Filters		
			4.3.2.1.2 Multiplying constant		
			4.3.2.1.3 Setting the decimal point	2(
		4.3.2.2	Channel "U"	2	
		4.3.2.3	Channel "P"	2	
		4.3.2.4	Channel "Fr"	2	
		4-3.2.5	Mathematic functions	2	
	4.3.3	Configurati	on mode - OUTPUT		
		4.3.3.1	Limits	2	
		4.3.3.2	Data output	2	
		4.3.3.3	Analog output		
		4.3.3.4	Proejction on the display	3 (
	4.3.4	Configurati	on mode - SERVICE		
		4.3.4.1	Access rights for User mode	3	
		4.3.4.2	Return to manufacture calibration	3	
		4.3.4.3	Instrument calibration	3	
		4.3.4.4	Menu language		
		4.3.4.5	New access password		
		4.3.4.6	Instrument identification.		
Error statements					
Technical data					
Instrument dimensions and installation					
Certificate of guarantee					
Decl	aration o	of conformi	tv	47	

INSTRUMENT DESCRIPTION 2.

DESCRIPTION

The OM 371PWR model is a universal 4 digit panel wattmeter, with independent measurement of AC voltage/ current, frequency, Power factoru and other quantities.

The instruments are based on an 8-bit microcontroller with precise RMS converter, that secures high accuracy, stability and easy operation of the instrument.

Programmable display projection

Measured quantity voltage (V_{PMS})

current (Apple)

real power (P) frequency (Hz)

with calculation reactive power (Q)

apparent power (S)

power factor (cos φ)

Settina manual, for the maximum value of the input signal, in "CM" it is possible to set arbitrary

projection on the display, e.g.: 0...250 V/0...5 A ⇒ 0...1.250 kW

-999 9999 Projection

Digital filters

Floating average 0/3/7 measurements from 2...100 measurements Exponential average n-th value from 2...100 measurements

Radius of insens. band of suppressed change of measured value

Mathematic functions

Min/max. value registration of min./max. value achieved during the measurement Tare

assigned to reset the display in case of non-zero input signal

Round-off setting the projection step

External control

Hold display/instrument/Menu blocking

Lock control kevs locking

Output

Limits 2 relays with switching contact,

> Limits have both adjustable hysteresis and optional delay of the switch-on. Reaching the limits is signalled by LED and at the same time by the switch-on of the relevant relay.

CONTROL

The instrument is set and controlled by five control keys located on the front panel. All programmable settings of the instrument are realised in two adjusting modes:

Configuration menu (hereinafter referred to as "CM") is protected by an optional numeric code and containis

complete instrument setting

User menu may contain arbitrary programming setting defined in CM with another selective restriction

(see, change)

All programmable parameters are stored in the EEPROM memory (they hold even after the instrument is switched

off).

The measured units may be projected on the display.


EXTENSION

Data outputs are for their rate and accuracy suitable for transmission of measured data for further projection or directly into the control systems. We offer isolated RS232 and RS485 with the ASCII protocol or MessBus.

Analog outputs will find their place in applications where further evaluating or processing of measured data in external devices is required. We offer universal analog output with the option of selection of the output type - voltage/current. The analog output value corresponds with the displayed data and its type and range are selectable in the programming mode.

3. CONNECTION


The supply lead for feeding the instrument should not be in the proximity of low-potential signals. Contactors, motors with larger input and other efficient elements should not be in the proximity of the instrument. The lead into the instrument input (the measured quantity) should be in sufficient distance from all power leads and appliances. Provided this cannot be secured, it is necessary to use shielded leads with connection to ground. The instruments are tested in compliance with standards for use in industrial area, yet, we recommend to abide by the above mentioned principles.




Grounding on terminal "E" must be connected at all times

Relay parameters specified in the technical data apply
for resistance load. Upon connection of the induction load
we recommend to fit the leads to relay 1 A with a fuse for
maximum load protection.

CONNECTION FOR MEASUREMENTS ON ONE PHASE




CONNECTION FOR MEASUREMENTS ON THREE PHASES



4. INSTRUMENT SETTING

The instrument is set and controlled by 5 control keys located on the front panel. By means of these control keys it is possible to browse through the operting program, to select and set the required values.



CONFIGURATION MODE

- · designated for professional service and maintenance
- · complete instrument setting
- · access is password protected
- authorization for "User mode"

USER MODE

- · designated for instrument service
- may contain setting the limits, analog and data output and brightness, with restriction as per the setting in "Configuration mode"

SYMBOLS USED IN THE INSTRUCTIONS

Œ

Indication of manufacture pre-setting

CONTROL KEYS FUNCTIONS

•	9	0	0	0	
MENU	ENTER	LEFT	DOWN	UP	
Measuring mode					
menu access	optional function	optional function	optional function	optional function	
Moving around in the	Moving around in the menu				
exit the menu without saving	move to next level	back to previous level		move to next item	
Setting/selecting - items					
cancel setting without saving	confirm selected item		move down	move up	
Setting - numbers					
cancel setting without saving	cancel selected number	move to higher decade	change of current figure - down -	change of current figure - up -	

SETTING THE DECIMAL POINT AND THE MINUS SIGN


DECIMAL POINT

Its selection is performed for each quantity independently in the "Channels" menu. Upon modification of the number to be adjusted transition behind the highest decade is performed by the control key 🕥, when the decimal point starts flashing. Positioning is performed by 💁.

MINUS SIGN

Its selection is performed independently for every item. The sign is set on the highest decade by the control key and it is placed between the digits "9" and "0". Confirmation is made by pressing Θ .

ACCESS INTO THE CONFIGURATION MODE



The code is always preset from manufacture to 0000. In case of loss of access password it is possible to use universal access code "8177"


4.1 GUIDE THROUGH MINIMUM INSTRUMENT SETTING


Access into the "Configuration menu"






2 Setting display projection







Setting the input

parameters - Channel I

CHRN I

Setting display projection for maximum value of input voltage

- range of the setting is ±9999

4.2 USER MENU

- · designed for instrument service
- may contain setting limits, analog/data output and brightness with restriction as per the setting in "Configuration mode"




Projection of items and their accessibility depends on the setting in "Configuration menu", items "RIGHTS"

4.2.1 USER MENU - INTERNAL VALUES RESETTING



Adjustable authorization of access into items see page 36

4.2.2 LIMITS - ENTERING THE VALUES



The process of setting Limit 2 is identical with the setting for Limit 1

Adjustable authorization of access into items, see page 37

LItt - Entering the limit values for status evaluations

LIMIT Setting the limit for relay switch-on

- in full range of the display

HY57 Setting hysteresis only in (+) values

- in full range of the display

Setting the beginning of the range of the limit switch-on

- in full range of the display


OFF. L Setting the end of the range of the limit switch-on

- in full range of the display

FIME. L Setting the offset of the limit switch-on

- in range 0...99,9 s

4.2.3 DATA OUTPUT - SETTING THE RATE



Adjustable authorization of access into items, see page 37

Setting the data output ERI II rate (baud) Rate - 600 Baud 800 Rate - 1 200 Baud 1200 Rate - 2 400 Baud 2400 Rate - 4 800 Baud 4800 Rate - 9 600 Baud 9600 Rate - 19 200 Baud 19200 Rate - 38 400 Baud 38400 Rate - 57 600 Baud 57600 Rate - 115 200 Baud 115200

4.2.3.1 DATA OUTPUT - SETTING THE INSTRUMENT ADDRESS






- setting in range 0...31
- manufacture setting 00

Adjustable authorization of access into items, see page 37

ANALOG OUTPUT - SETTING THE RANGE 4.2.4





Setting the analog output AN DUT range

- the analog output is isolated and its value corresponds with the displayed data. It is fully programmable, i.e. it allows to assign the AO limit points to any two arbitrary points of the entire measuring range

Assigining the displayed RO, MIN value to the beginning of the AO range

- range of the setting is ±50 000

Assigining the displayed 80 M8% value to the end of the AO

range


- range of the setting is ±50 000

4.3 CONFIGURATION MENU

- · designated for professional service and maintenance
- · complete instrument setting
- access is protected by password or a shorting link on the input connector
- authorization for "User mode"



4.3.1 CONFIGURATION MODE - INPUTS




The basic instrument parameters are adjusted in this menu

CLERR Resetting the internal values of the instrument

EDNF16 Basic instrument setting

RUX.INP. Setting the auxiliary input


4.3.1.1 INTERNAL VALUES RESETTING



EL. TRP. Tare resetting

EL. M.M. Resetting the min and max value of the measurement

4.3.1.2.1 SETTING THE MEASURING RATE



Setting the instrument measuring rate

8.5 m/s

Rate - 0,6 measurements/s


Rate - 1,2 measurements/s

1.2 m/s

Rate - 2,5 measurements/s

S m / s Rate - 5 measurements/s

4.3.1.2.2 SETTING THE INPUT FILTER



FILTER Setting the input filter


 floating filter with the option of setting the number of measurements

OFF The function is off

Floating filter from 3 measurements

Floating filter from 7 measurements

4.3.1.2.3 SETTING THE INPUT AC FILTER



Setting the input AC filter - suppressing the dc comp.

 allows for measurement of the alternating component of the input signal only


*ISREL. The function is off

ENBELE

 measures only the alternating component of the input signal

The function is on

4.3.1.2.4 SETTING THE INPUT QUANTITIES FOR MIN/MAX VALUE EVALUATION



Setting for evaluation of the min/max value

- allows to assign the quantity from which the min/max value on the display is evaluated

* ISABL. The function is off

CHRN. I Value from channel I "Current"

"Value from channel O
"Value from channel P
"Power Output"

CHRN. F. Value from channel Fr. - Frequency

Value from channel U


FILT. I Filtered value from channel I - "Current"

FILT. U
Filtered value from channel
U - "Voltage"

FILT P. Filtered value from channel P - "Power Output"


MRTH.FN... Mathematic functions

4.3.1.3 AUXILIARY INPUTS



RUX.INP.	Setting the function "Hold"
н.:15Р.	The "Hold" signal blocks the displayed value
H. F.R.S.R. and analog of	The "Hold" signal blocks the displayed value, the data utput functions
H. RLL	The "Hold" sgnal blocs the entire instrument
L.PR55U.	Blocking access into the Configuration menu
TARE	Activation of the "Tare" function

4.3.2 CONFIGURATION MODE - CHANNELS



The basic parameters of the instrument input values are adjusted in this menu

Setting the parameters and the range of the measuring

channel I - "Current"

CHRN. U Setting the parameters and the range of the measuring

channel U - "Voltage"

CHRN. P Setting the parameters and the range of the measuring


channel P - "Power Output"

CHRN.E. Setting the parameters and

the range of the measuring channel Fr - "Frequency"

Setting the instrument mathematic functions

4.3.2.1 SETTING THE MEASURING "CHANNEL I"



CHRN I

Setting the input parameters - Channel I

MAX. I


Setting display projection for maximum value of the

input signal

- range of the setting is -99999...999999

4.3.2.1.1 SETTING THE MEASURING "CHANNEL A" - FILTERS





Setting the digital filters

CONSE. 1 Setting the Filtration

 this menu is displayed always after selection of a particular type of filter

Filters are off

Selection of the exponential

 calculation is from a selected number of measurements (range 2...100)

N-TH Selection of the n-th value

 this filter allows to drop n-1 values and for further processing use every n-th measured value (range 2...100 measurements)

UNSEN. Selection of the band of insensitiveness


- this filter enables to stabilize the resulting value. The measurement result is understood as the previous value, provided the measured value is not higher than the previous + P or smaller than previous - P. The value "±P" indicates the band of insensitiveness in which the measured value may change without affecting the result - the change of the disalayed data (range 0,00001...100 000)

ROUNE. Meas

Measured value round-off

- it is set by arbitrary number, which determines the step of projection (e.g., 2.5 - 0, 2.5, 5, 7.5, etc.)

4.3.2.1.2 MULTIPLYING CONSTANT



PREFIX Multiplying constant


 the constant allows for another mathematic calculation with the option of extended projection of the measuring units

Constant 0,001, description

- NULL Constant 1, w/o description

Constant 1000, description


4.3.2.1.3 SETTING THE DECIMAL POINT




FORMAT Setting the decimal point

 the instrument allows for classic projection of a number with placement of the decimal point (0000/000,0/00,00/0,000) and projection with floating point, allowing to display the number in its most precise form "FLOAT. P."

4.3.2.2 SETTING THE MEASURING "CHANNEL U"






Setting display projection for maximum value of the input signal

- range of the setting is 999999

Further settings are identical with measuring channel "I"

4.3.2.3 SETTING THE MEASURING "CHANNEL P"





* I 58EL. The function is off

ENRELE Calculation of 3-phase

- power output is on


 the value is calculated with the assumption of a balanced demand in all phases
 - for P, S Q the value is multiplied by 3




Further settings are identical with measuring channel "I"


channel "I"

4.3.2.4 SETTING THE MEASURING "CHANNEL FR"






4.3.2.6 MATHEMATIC FUNCTIONS



 $A \sin^5 x + B \sin^4 x + C \sin^3 x + D \sin^2 x + E \sin x + F$

SIN X

4.3.2.3 MATHEMATIC FUNCTIONS - MULTIPLYING CONSTANT



PREFIX Multiplying constant

 the constant allows for another mathematic calculation with the option of extended projection of the measuring units


Constant 0,001, description

- NULL Constant 1, w/o description

Constant 1000, description

This menu item is displayed only when the options S, Q, cos Fi are selected in the "FUNCTIONS" item and the mathematic functions (MAT. Fl are not active

4.3.2.4 SETTING THE DECIMAL POINT




FORMAT Setting the decimal

 the instrument allows for classic projection of a number with placement of the decimal point (0000/000,00/00,000) and projection with floating point, allowing to display the number in its most precise form "PLOV."

This menu item is displayed only when the options S, Q, cos Fi are selected in the "FN." item and the mathematic functions (MATH. F) are not active

4.3.2.4 SETTING THE DECIMAL POINT




Setting the decimal point

 the instrument allows for classic projection of a number with placement of the decimal point (0000/000,0/00,000,000) and projection with floating point, allowing to display the number in its most precise form "FLOAT. P."

The menu is displayed only when "MATH.F" are active or the inputs "FN." U, I or Fr. are selected

4.3.2.6.3 MATHEMATIC FUNCTIONS - DESCRIPTION ON THE DISPLAY




Setting the measuring units on the display upon projection of the mathematic functions

 in this menu we set individual projection of the symbol of mathematic function which is independent of the projection of the measured quantity description and it is displayed only with the given function

The menu is displayed only when "MATH.F" are active or the inputs "FN." U, I or Fr. are selected

4.3.3 **CONFIGURATION MODE - OUTPUT**




Setting the function and type LIMIT of the limits switch-on Setting the data output type

£818 and parameters Setting the analog output

RN. DUT. type and parameters Setting the permanent £158.

and temporary display projection and assignment of further projection of internal data to arbitrary instrument control keys

4.3.3.1.1 LIMITS - SETTING THE DATA FOR EVALUATION



The setting for Limit 2 is identical with the setting for Limit 1

The menu is dynamic, i.e. the items are displayed in dependance on the set type of limits.

HYSTER. ⇒ LIMIT + HYST. + TIME. L FROM... ⇒ ON. L + OFF. L

The limit will be evaluated from the output of "Channel U" after modification by digital filters

The limit will be evaluated FILT.P from the output of "Channel


P" after modification by digital filters

The limit will be evaluated FILT.Fr. from the output of "Channel Fr." after modification by digital filters

The limit will be evaluated MRTH.EN. from the mathematic

functions output

4.3.3.1.2 LIMITS - SETTING THE TYPE OF LIMITS



Setting the type of limits

A limit has a boundary, hysteresis and delay


- for this regime the "LIMIT" parameters are set, at which the limit shall react and is adjustable within full range of the display, "HYST.." is an auxiliary parameter preventing oscillation at unsteady value, it is adjustable only in plus values. The limit parameter is "TIME L." determining the offset of the relay switch-on from the time of exceeding the set limit in range 0,0... 99,9 s

Limit is in the regime switch-on "from - to"

- for this regime the parameters "ON. L.." and "OFF L" are entered between which the limit is to switch-on, they are adjustable within the full display range


The setting for Limit 2 is identical with the setting for Limit 1

4.3.3.1.3 LIMITY - SETTING THE RELAY MODE



The setting for Limit 2 is identical with the setting for Limit 1

4.3.3.1.4 LIMITY - SETTING THE BOUNDARIES



The setting for Limit 2 is identical with the setting for Limit 1



LIMIT Setting the boundary for relay switch-on

- in full range of the display

HY57. Setting hysteresis only in (+) values

- within 1/10 of the display range

Setting the beginning of the range of the limit switch-on

- in full range of the display


OFF. L Setting the end of the range of the limit switch-on

- in full range of the display

TIME. L Setting the offset of the imit switch-on


- in range 0...99,9 s

4.3.3.2.1 DATA OUTPUT - SETTING THE TRANSMISSION RATE



8 <i>RU</i> :	Setting the transmission rate (baud)
500	Rate - 600 Baud
1200	Rate - 1 200 Baud
2400	Rate - 2 400 Baud
4800	Rate - 4 800 Baud
9600	Rate - 9 600 Baud
19200	Rate - 19 200 Baud
38400	Rate - 38 400 Baud
57600	Rate - 57 600 Baud
115200	Rate - 115 200 Baud

4.3.3.2.2 DATA OUTPUT - SETTING THE INSTRUMENT ADDRESS




	etting the instrument
--	-----------------------


- setting in range 0...31
- manufacture setting 00 DEF

4.3.3.2.3 DATA OUTPUT - SETTING THE DATA PROTOCOL







4.3.3.3.1 ANALOG OUTPUT - SETTING THE DATA FOR EVALUATION




RO. INP.	Setting the input "quantity" for evaluation tput
₽ISREL.	AO nebude vyhodnocována
ЕНЯМ. І	AO will be evaluated from output of "Channel I"
EHRN. U	AO will be evaluated from output of "Channel U"
CHRN.P	AO will be evaluated from output of "Channel P"
EHRN, F.	AO will be evaluated from output of "Channel Fr."
FILT. I	AO will be evaluated from FILTER.value of "Channel I"
FILT. U	AO will be evaluated from FILTER.value of "Channel U"
FILT, P	AO will be evaluated from FILTER.value of "Channel P"
FILT, Fr.	AO will be evaluated from FILTER.value of "Channel Fr."
МЯТН,ЕМ.	AO will be evaluated from the math.functions output

4.3.3.3.2 ANALOG OUTPUT - SETTING THE TYPE





4.3.3.3.3 ANALOG OUTPUT - SETTING THE RANGE



RN OUT

Setting the range of the analog output

 analog output is isolated and its value corresponds with the displayed data. It is fully programmable, i.e. it allows to assign the AO limit points to any two arbitrary pointsof the entire measuring range

AO range

Assigning the displayed value to the beginning of the


- range of the setting is -99999...999999


Assigning the displayed value to the end of the

AO range


- range of the setting is -99999...999999

4.3.3.4 DISPLAY PROJECTION







4.3.3.4.1 DISPLAY PROJECTION - PERMANENT



4.3.3.4.2 DISPLAY PROJECTION - AFTER PRESSING "LEFT"





LEFT	Assigning function to the control key "LEFT"
\$1588L.	The control key has no function
NUL. MM.	Resetting the min/max. value

Direct access to selected

Direct accomenu item
- see setting "MENU"

TEMP. N. Projection of temporary value

- after pressing the selected value will be displayed with flashing DP for approx. 2 s

CL. TRR. Tare resetting

TEMPOR. After selection of item "TEMP. N." from menu "LEFT" the following options are available

 in this menu we may select value for temporary display projection (after pressing ♠), which will be projected for approx 2s with flashing DP

EHRN. I	Value of "Channel I"
CHRN. U	Value of "Channel U"
EHRN, P	Value of "Channel P"
EHRN, F.	Value of "Channel Fr."
FILT. I	Value of "Channel I" after Filtration
FILT.U	Value of "Channel I" after Filtration
FILT.P	Value of "Channel I" after Filtration
FILT, Fr.	Value of "Channel I" after Filtration
МЯТН,ЕМ.	Value of the "Mathematic function"
14714	Value of the "Minimum

measuring value"


Value of the "Maximum measuring value"


Tare value

LIM | Value of "Limit 1"

MIN

LItt 2 Value of "Limit 2"





4.3.3.4.4 DISPLAY PROJECTION - AFTER PRESSING "DOWN"

↑ ⊚	_					
•	⊖ →				←0	
0	INPUT5	LIMIT	5H0W	FOREV.	₽ISREL.	
ŧ	CHRNEL.	: RTR	SETTIN	LEFT	CHRN. I	
	ОИТРИТ.	RN. DUT.	ЕРІБНТ	TEMPOR.	CHRN.U	
	SERVIC.	\$ 15R		MENU	CHRN.P	
				UP	EHRN, F.	
				# DUN	FILT. I	
				ENTER	FILT. U	
					FILT, P	
					FILT.Fr.	
					MRTH.FN	
					NIM	
					MAX.	
					TRRE	
ŧ					LIM I	
0					LIM 2	

; OHN	Assigning function to the control key "DOWN"
#1588L.	The control key has no function
CHRN. I	Value of "Channel I"
CHRN. U	Value of "Channel U"
CHRN.P	Value of "Channel P"
EHRN.F.	Value of "Channel Fr."
FILT. I	Value of "Channel I" after Filtration
FILT. U	Value of "Channel I" after Filtration
FILT.P	Value of "Channel I" after Filtration
FILT.Fr.	Value of "Channel I" after Filtration
мятн.ғи.	Value of the "Mathematic function"
MIN	Value of the "Minimum measuring value"
MAX	Value of the "Maximum measuring value"
TARE	Tare value
LIM I	Value of "Limit 1"
LIM 2	Value of "Limit 2"


4.3.3.4.5 DISPLAY PROJECTION - AFTER PRESSING "ENTER"

-0 INPUTS LIMIT SHON FOREV. OFF : RTR SETTIN CHRNEL. LEFT TRRE OUTPUT. AN. OUT. ERIGHT TEMPOR. SHON SERVIC. ‡ ISP. MENU MATH,FN.. Œ UР 1 DHN ENTER

ENTER	Assigning function to the control key "ENTER"
OFF	The control key has no function
TRRE	Display taring
SHOU	Projection of selected values


MRTH.FN... Value of the "Mathematic function"

4.3.3.4.6 DISPLAY PROJECTION - BRIGHTNESS




ЕРІСНІ	Setting the display brightness
100%	Brightness 100%
<i>ច</i> ::	Brightness 0 %, display is off
	itches off after approx. 10 s after pressing any key
25%	Brightness 25 %
50%	Brightness 50 %
75%	Brightness 75 %

4.3.4 CALIBRATION MODE - SERVICE





4.3.4.1.1 SETTING THE ACCESS RIGHTS FOR "USER MODE" - RESETTING TO ZERO



R ELR.	Authorization for the instrument internal values
resetting	

M. H. Authorization for item "N. MM", permitted resetting of the Min/max. value


Authorization for item "N. TARE", permitted resetting of the tare

The following parameters may be selected in all items


The item is not displayed in "UM"

ENRELE The item has full access in "UM"

4.3.4.1.2 SETTING THE ACCESS RIGHTS FOR "USER MODE" - LIMITS



The menu is dynamic, i.e. the items are displayed in dependance on the set type of limits.



LIMIT Authorization for item "LIMIT", setting the boundary

Authorization for item "HYST.", setting hysteresis

Authorization for item "ON. L.", setting the beginning of the switch-on (from-to)

Authorization for item "OFF. L.", setting the end of the

Authorization for item "TIME L.", setting the offset of the switch-on


The following parameters may be selected in all items

*1588L. The item is not displayed in "UM"

The item is displayed in "UM" but cannot be changed

The item has full access in "UM", including editing

4.3.4.1.3 SETTING THE ACCESS RIGHTS FOR "USER MODE" - OUTPUTS



Authorization for item "DATA", setting the data

Authorization for item "AN. OUT.", setting the analog output

The following parameters may be selected in all items


The item is not displayed in "UM"

The item is displayed in "UM" but cannot be changed

indinged

The item has full access in "UM", including editing

4.3.4.1.4 SETTING THE ACCESS RIGHTS FOR "USER MODE" - PROJECTION



Authorization for temporary projection of internal values "SHOW" from menu "OUTPUT. - DISP"

 it sets authorization for temporary projection of the instrument internal values

The following parameters may be selected in this item


₽ISREL.

The item is not displayed in "UM"

ENRELE

The item has full access in "UM"

4.3.4.1.5 SETTING THE ACCESS RIGHTS FOR "USER MODE" - BRIGHTNESS



Authorization for item "BRIGHT", setting the display brightness

The following parameters may be selected in this item


:1588L.

The item is not displayed in "UM"

SHOU changed The item is displayed in "UM" but cannot be

The item has full access in "UM", including editing

4.3.4.2 RESTORATION OF MANUFACTURE CALIBRATION/SETTING



RESTOR. Restoration of manufacture calibration or instrument setting

 in case of incorrect setting or calibration it is possible to return to manufacture setting. Prior execution of the changes you will be asked to confirm your selection "YES"?


CALIE.

Restoration of manufacture

SETTIN. Restoration of manufacture setting and calibration

 reading the manufacture calibration and original setting of items in the menu (DEF)

4.3.4.3 INSTRUMENT CALIBRATION



Projection values for "MAX I" and "MAX U" are entered to the respective channel

ERL IE Instrument calibration

 in this menu instrument calibration may be performed. Prior execution of the changes you will be asked to confirm your selection and choose the calibration range "YES"?

MIN.VI. Entering and connecting reference signals for

minimum input value


 prior confirmation of the selection both reference signals must already be connected


MR#. VI. Entering and connecting reference signals for

maximum input value


- prior confirmation of the selection both reference signals must already be connected

4.3.4.4 LANGUAGE VERSION FOR THE INSTRUMENT MENU






4.3.4.5 SETTING NEW ACCESS PASSWORD





- this option allows to change the numeric code which blocks the access into the instrument "Configuration mode". Range of the numeric code is 0...9999
- The code is always preset from manufacture to 0000. In case of loss of access password it is possible to use universal access code "8177".

4.3.4.6 INSTRUMENT IDENTIFICATION



IF ENT Projection of the instrument version

- the display shows the type identification of the instrument with the number of revision
- instrument with the number of revision

 instrument name input program version date SW (MM/DD/YY),
 - e.g.: OM371-POWER > 041-16 > 170603

5. TABLE OF SYMBOLS

The instrument allows to add two descriptive characters to the classic numeric formats (at the expense of the number of displayed places). The setting is performed by means of a shifted ASCII code. Upon modification the first two places display the entered characters and the last two places the code of the relevant symbol from 0 to 95. Numeric value of given character equals the sum of the numbers on both axes of the table.

Description is cancelled by entering characters with code 00

	0	1	2	3	4	5	6	7		0	1	2	3	4	5	6	7
О		7.	"	Ħ	5	54	ď	,	0		!	"	#	\$	%	&	•
8	(;	*	+	,			,'	8	()	*	+	,	-		/
16	8	1	2	3	ч	5	Б	7	16	0	1	2	3	4	5	6	7
24	8	9	19	16	()		7.	24	8	9	:	;	<	=	>	Ś
32	e	R	E	Ε	<i>\$</i>	Ε	F	5	32	@	Α	В	С	D	Ε	F	G
40	Н	Ι	J	ľ	L	11	N	0	40	Н	1	J	K	L	Μ	Ν	0
48	ρ	G	R	5	Ţ	U	l'	11	48	Р	Q	R	S	T	U	٧	W
56	Ж	Y	Z	۲	١,	J	Π	_	56	Χ	Υ	Z	[\]	^	_
64	,	۵	ь	c	ď	<u>e</u>	F	5	64	`	а	b	С	d	е	f	g
72	h	1	J	k	1	m	n	o	72	h	i	i	k	-1	m	n	0
80	ρ	G	r	ı	٤	U	v	P 4	80	р	q	r	S	t	U	٧	w
88	Х	Y	L	-(1)-	0		88	х	У	z	{	-	}	~	

6. DATA PROTOCOL

The instruments communicate via serial line RS232 or RS485. For communication they use either ASCII protocol and communication is running in the following format:

ASCII: 8 bit, no parity, one stop bit

Both the transmission rate and the address are adjustable in the instrument menu.

Manufacture setting always presets the ASCII protocol, rate of 9600 Baud, address 00.

COMMANDS FOR INSTRUMENT OPERATION

The commands are described in the description which can be found at www.orbit.merret.cz/rs. The command consists of a couple number-letter, where the letter size is of importance.

Symbol	Meaning	Symbol	Meaning
(1)	Send unit value	G	Complete number
(3	Set unit value	O	Selection = complete number
0	Perform relevant action	0	Decimal number
		0	Text - printable ASCII characters
		0	Intel HEX format

Legend								
#		35 23н		Beginning of the command				
Α	Α	031		Two signs of the inst. address (sent in ASCII - decades and units, ex."01")				
<cr> 13 0D_H</cr>		0D _H	Carriage return					
<sp> 32 20_H</sp>		20 _H	Space					
N	Р			Number and command - command code				
[D			Data - usually signs "0""9","-","." ; (D) - dp. and (-) may prolong data				
R		30 _H 3F _H		Relay status; zero bit corresponds with 1st relay, 1st bit with 2nd relay, etc.				
!		! 33 21 _H		Positive command confirmation (ok)				
? 63 3F _H		3F _H	Negative command confirmation (bad)					
> 62 3E _H		3E _H	Beginning of the transmitted data					

7. ERROR STATEMENTS

ERROR	REASON	ELIMINATION
E.Unde.	range underflow (A/D transducer)	change the input signal value or change display projection
E.O. e. r.	range overflow (A/D transducer)	change the input signal value or change display projection
E.At C	A/D transmission error	upon repeated error statement send the instrument for repair
E.s a L a.E	distrupted data integrity in EEPROM, error upon data storage	upon repeated error statement send the instrument for repair
E.5HDN	projection error, setting the DP and description at the same time	change of setting
EMEM.	EEPROM memory error	"Def" values will be used in emergency, needs to be sent for repair
E.L.o.PNR	value cannot be measured (only for Power factor)	input signal control (input brackets have zero value of voltage/current)

8. TECHNICAL DATA

INPUT

range jis fixed, as per order

Voltage: 0...10 V 1 MOhm
0...30 V 1 MOhm
0...60 V 1 MOhm
0...100 V 1 MOhm
0...150 V 1 MOhm
0...250 V 1 MOhm

0...250 V 1 MOhm 0 450 V 1 MOhm

Current: 0...60 mV 1 M0hm 0...150 mV 1 M0hm 0..300 mV 1 M0hm

> 0...40 mA < 60 mV 0...400 mA < 60 mV 0...1 A < 60 mV 0...5 A < 60 mV

Input frequency: 0...400 Hz
Measured quantities Voltage (V_{vur})

Current (A_{RMS})
Active power (P)
Frequency (Hz)

with calculation Reactive power (Q)
Apparent power (S)

Power factor (cos φ)

PROJECTION

Display: 999999, intensive red or green 14-segment LED, digit

height 14 mm

Projection: -99999...99999

Decimal point: adjustable - in Configuration mode
Brightness: adjustable - in programming mode

INSTRUMENT ACCURACY

Temp.coefficient: 100 ppm/°C Accuracy: ±0,2% of range

Rate: 0,6 - 1,2 - 2,5 - 5 measurements/s Overload capacity: 10x (t < 100 ms), 2x (long-term)

Digital filter exponential. N-th value, radius of insensitiveness.

round-off

Functions: Tare - display resetting

Hold - stop measuring (upon contact)
Blocking keyboard (upon contact)
Blocking the access into "CM"
Min/max. value resetting

Projection of measured units see documentation

Watch-dog: reset after 1,2 s Calibration: at 25°C and 40 % r.h.

COMPARATOR

Type: digital, adjustable in the menu

Limits: -999...3999

Hysteresis: 0...999

Delay: 0...99,9 s

Reaction: < 30 ms

Outputs: 2x relays with switching contact (230 VAC/30 VDC, 3 A)*

Relay: 1/8 HP 277 VAC. 1/10 HP 125 V. Pilot Duty D300

DATA OUTPUTS

Data format: 8 bit + no parity + 1 stop bit (ASCII)

Rate: 600...115 200 Baud RS 232 isolated

RS 485: isolated, addressing (max. 31 instruments)

ANALOG OUTPUTS

Type: isolated, programmable with resolution of max.

10 000 points, analog output corresponds with the displayed data, type and range are adjustable

Non-linearity: 0,2 % of range TC: 100 ppm/°C

Rate: response to change of vigue < 100 ms

Voltage: 0...2 V/5 V/10 V

Current: 0...5/20 mA/4...20 mA (compensation up to 600 0hm)

POWER SUPPLY

Options: 24/110/230 VAC, 50/60 Hz, ±10 %, 5 VA

10...30 VDC/max. 300 mA (24 VDC/110 mA),

Protection: by a fuse inside the instrument

VAC (T 80 mA), VDC (T 630 mA)

MECHANIC PROPERTIES

Material: Norvl GFN2 SE1, incombustible UL 94 V-I

Dimensions: 96 x 48 x 120 mm Panel cut-out: 90,5 x 45 mm

OPERATING CONDITIONS

Connection: connector terminal board, conductor sec. up to 2.5 mm²

Stabilization period: within 15 minutes after switch-on

 Working temp.:
 0°...60°C

 Storage temp.:
 -10°...85°C

 Cover:
 IP65 (front panel only)

Construction: safety class I

Overvoltage cat.: EN 61010-1, A2; for pollution degree II

III. - instrument power supply (300 V)
II. - input, output, excitation (300 V)

EMC: EN 61000-3-2+A12; EN 61000-4-2, 3, 4, 5, 6, 8, 11;

EN 55022, A1, A2

Math. functions:

9. INSTRUMENT DIM. AND INSTALLATION


Front view



Panel cut




Side view




Panel thickness: 0.5...20 mm

Instrument installation

- 1. insert the instrument into the panel cut-out
- 2. fit both travellers on the box
- 3. press the travellers close to the panel





Instrument disassembly

- 1. slide a scre-driver under the traveller wing
- 2. turn the screw-driver and remove the traveller
- 3. take the instrument out of the panel

10. CERTIFICATE OF GUARANTEE

Výrobek	OM 371 PWR
Туре	
Manufacturing No.	
Date of sale	JARANTEE
Defects occuring during this charge.	onths from the date of sale to the user applies to this instrument. period due to manufacture error or due to material faults shall be eliminated free or n and construction the guarantee shall apply provided that the instrument was connected
and used in compliance with	
- unavoidable	amage of unqualified person incl. the user
The manufacturer performs the	ne guarantee and post-guarantee repairs unless provided for otherwise.
	Stamp, signature

11. DECLARATION OF CONFORMITY

Company: ORBIT MERRET, spol.s r.o.

Klánova 81/141 142 00 Prague 4 Czech Republic

Trade licence No.: 00551309

Manufacturer: ORBIT MERRET, spol.s r.o.

Vodňanská 675/30 198 00 Prague 9 Czech Republic

declares at its full responsibility that the product presented hereunder meets all technical requirements, is safe for use when utilised under the terms and conditions determined by Orbit Merret, spol.s r.o. and that our company has taken all steps to ensure conformity of all products of the types listed hereunder, which are being brought out to the market, with technical documentation and requirements of the appurtenant statutory orders.

Product: 3 3/4 digit panel programmable instrument

Type: OM 371, in versions: DC, PM, DU, PWR, OHM, RTD, T/C

Mode of assess. of conformity: §12, par. 4 b, d of Act No. 22/1997 Coll.

Conformity is assessed pursuant to the following standards:

el. safety: EN 61010-1

EMC: EN 50131-1, čl. 14 a čl. 15

EN 55022

EN 61000-3-2 + A12, Cor. 1, change A1, change A2

EN 61000-4-2 EN 61000-4-3 EN 61000-4-4 EN 61000-4-5 EN 61000-4-8 EN 61000-4-11

and statutory orders:

el. safety: No. 168/1997 Sb. EMC: No. 169/1997 Sb.

As supporting documentation serve the protocols of authorised and accredited organizations:

VTÚE Praha, testing laboratory No.1158 accredited by ČIA, o.p.s. in compliance with EN ISO/IEC 17025

Place and date of issuance: Prague, November 21, 2001 Miroslav Hackl v.r.

General Manager

ORBIT MERRET, spol. s r.o.

Vodnanska 675/30 198 00 Prague 9 Czech Republic

www.orbit.merret.cz

tel: +420 - 281 040 200 fax: +420 - 281 040 299 e-mail: orbit@merret.cz

Austria

ING.E.GRUBER GmbH Edu. Kittenberger Gasse 97 Top2 A-1230 Wien tel: +43 - 1 - 869 23 39-0 fray: +43 - 1 - 865 18 75

e-mail: office@gruber-components.at www.gruber-components.at

The Netherlands

AE SENSORS B.V.
J. Valsterweg 92
3301 AB Dordrecht
tel: +31 - 78 - 621 31 52
fax: +31 - 78 - 621 31 46
e-mail: aesensors@aesensors.nl

Switzerland

ORBIT CONTROLS AG
Zürcherstrasse 137
8952 Schlieren
tel: +41 - 1 - 730 27 53
fax: +41 - 1 - 730 27 83
email: info@orbitcontrols.ch
www.orbitcontrols.ch

USA

1711 Townhurst Dr.
Houston, Texas 77043-2899
tel: +1 - 713 - 461 21 31
fax: +1 - 713 - 461 82 83
e-mail: sales@metrix1.com
www.metrix1.com

METRIX Instruments Co.

Germany

MEGATRON Elektronik AG & Co. Hermann-Oberth-Str. 7 85640 Put2brunn/München tel: +49 - 89 - 460 94 - 0 fax: +49 - 89 - 460 941 01 e-mail: sales@megatron.de www.megatron.de

Russian Federation

PO <INTERFACE> a.b. 3408 Krasnodar, 350044 tel: +1 - 8612 - 660 483 fax: +1 - 8612 - 623 000 e-mail: if@au.ru

Turkev

ALFA ELEKTRONIK Ltd.
Baglarbasi Mah. Ergenekon No: 33
TR - 81540 Mallepe - ISTANBUL
tel: +90 - 216 - 442 39 49
fax: +90 - 219 - 305 54 50
e-mail: sb@elmak.com.tr
www.alfa-technik.com

Lithuania

RIFAS UAB
Tinklu g. 29a
IT-5300 Panevéžys
tel: +370 - 5 - 510 400
fax: +370 - 5 - 582 729
e-mail: sales@metrix1.com
www.metrix1.com

Slovakia

TECHREG, s.r.o.
Dukelských hrdinov 2
984 22 Lučenec
tel: +421 - 47 - 433 15 92
fax: +421 - 47 - 433 15 92
e-mail: tertneg@bb.psg.sk
www.techreg.sk

Ukraine

OOO <KOTRIS>

Nesterova 3, Office 907 030 57 Kyjev tel: +44 - 446 - 21 42 fax: +44 - 446 - 21 42 e-mail: metrix-ua@svitonline.com